

# **TMS-220**

## **U S B   t o   I <sup>2</sup> C <sup>TM</sup>   H o s t   A d a p t e r**

### **User's Manual**

Revision A

---



## **Triangle Micro Solutions, Inc.**

25 Oak Hollow Court  
Louisburg, North Carolina 27549  
USA

**Email:** [sales@trianglemicro.com](mailto:sales@trianglemicro.com)  
[service@trianglemicro.com](mailto:service@trianglemicro.com)  
**On-line visit:** <http://www.trianglemicro.com>  
**By Phone:** (919) 495-0622  
**Document Revision:** A  
**Date:** February 2007  
**Supports:** TMS-220 Firmware Revision 1.0

### **Limited Warranty**

Triangle Micro Solutions, Inc. warrants this product for a period of one year from the original date of purchase. This warranty is extended to the original purchaser only. This warranty only covers defects in material or workmanship for the TMS-220 module only. The interface cables or other accessories are not covered. If the TMS-220 module fails to operate properly within this one year period, it will be repaired or replaced at the discretion of Triangle Micro Solutions, Inc. The consumer is responsible for shipping charges to return products for any reason. The consumer must contact Triangle Micro Solutions and inform us prior to returning any merchandise. This warranty is void if, in the opinion of Triangle Micro Solutions, Inc., the product has become nonfunctional for any of the following reasons: damaged by accident, misuse, or modified in anyway by unauthorized personnel.

### **Statement of Non Compliance**

This device generates and uses radio frequency (RF) energy and could emit sufficient levels of RF energy to interfere with other devices. An increase in emissions is possible when this device is connected to external equipment. This device is intended to be used in a laboratory environment only. It has not been tested for compliance with the limits for a class A computing device pursuant to subpart J of part 15 of the FCC regulations. It is the user's responsibility to take corrective action if interference occurs.

### **USE THIS DEVICE AT YOUR OWN RISK!**

Please read this documentation before using the TMS-220. While the TMS-220 can be a useful tool, it must also be understood that the TMS-220 could render target devices non-functional. If you are using the TMS-220 to write data to EEPROM memory devices, be sure to make a back up copy of any data that is critical for the operation of the device. Triangle Micro Solutions is not responsible for any malfunctions, damage, loss of business, or loss of data caused by the TMS-220 regardless of how the damage occurs. These devices are not designed for use in life support appliances, devices, systems or in any application where a malfunction may reasonably be expected to cause personal injury or loss of life.

### **Trademarks**

Windows® is a trademark of Microsoft® Corporation  
I<sup>2</sup>C™ is a trademark of Philips Corporation

**Copyright © 2007, Triangle Micro Solutions, Inc.  
All Rights Reserved.**

Copyright © 2007 - Triangle Micro Solutions, Inc. All rights reserved.



## Record of Revisions

Revision	Date	Section	Change
A	28-Feb-07	All	Initial release of document



# Table of Contents

TABLE OF FIGURES .....	9
<b>1 INTRODUCTION .....</b>	<b>11</b>
1.1 DESCRIPTION .....	11
1.2 SUPPORTING DOCUMENTS .....	11
1.3 FEATURES .....	11
1.4 SPECIFICATIONS .....	12
1.5 APPLICATIONS .....	13
<b>2 HARDWARE .....</b>	<b>14</b>
2.1 INTERFACE MODULE.....	14
2.2 TMS-220 INTERFACE CABLE .....	15
2.3 CUSTOM INTERFACE SOLUTION.....	16
2.4 INTERFACE CABLE DATA .....	17
<b>3 USING THE TMS-220 .....</b>	<b>18</b>
3.1 INSTALLING THE TMS-220 INTERFACE MODULE .....	18
3.2 INSTALLING THE USB PORT DRIVER .....	18
3.2.1 <i>Identifying the Serial Port (COM Port)</i> .....	21
3.2.2 <i>Changing the Serial Port (COM Port)</i> .....	21
3.3 CONNECTION TO I <sup>2</sup> C BUS.....	21
3.4 SOFTWARE .....	22
3.5 FIRST TIME USAGE .....	23
3.6 ASCII COMMAND PROTOCOL .....	23
3.6.1 <i>Command Summary</i> .....	25
3.6.1.1 Command: /A – Address Configuration .....	26
3.6.1.2 Command: /B – Reboot the TMS-220.....	27
3.6.1.3 Command: /C – Show the Current Configuration .....	28
3.6.1.4 Command: /D – Discover Network Nodes .....	29
3.6.1.5 Command: /F – Format Options.....	30
3.6.1.6 Command: /G – General Call Support.....	31
3.6.1.7 Command: /H - Help Command .....	32
3.6.1.8 Command /K: Set or Read the Master Clock Rate .....	33
3.6.1.9 Command /M: Set or Read the Mode .....	34
3.6.1.10 Command /X: Radix Control .....	35
3.6.1.11 Command /R: Read I <sup>2</sup> C Slave Device .....	36
3.6.1.12 Command: /S Serial Number .....	37
3.6.1.13 Command /W: Write to I <sup>2</sup> C Slave Device .....	38
3.7 I <sup>2</sup> C MASTER OPERATING MODE .....	39
3.8 I <sup>2</sup> C SLAVE OPERATING MODE .....	39
<b>4 TROUBLESHOOTING .....</b>	<b>41</b>
4.1 NO PROMPT SEEN WHEN ENTER KEY PRESSED .....	41
4.2 ERROR MESSAGES .....	42





## Table of Figures

Figure 2-1: TMS-220 I <sup>2</sup> C Host Adapter (Interface Module) .....	14
Figure 2-3: Cable for Custom Applications (option P/N TMS-CBL) .....	16
Figure 2-4: RJ-45 Connector on TMS-220 (Front View) .....	17
Figure 3-1: Found New Hardware Dialog .....	18
Figure 3-2: Choose Installation Mode .....	19
Figure 3-3: Windows <sup>®</sup> Logo Test Warning .....	19
Figure 3-4: Software Installation Progress .....	20
Figure 3-5: Final Installation Dialog .....	20
Figure 3-6: Typical I <sup>2</sup> C Bus Connection .....	22
Figure 3-7: TMS-220 Slave Response to Write Command .....	39
Figure 3-8: TMS-220 Slave Response to Read Command .....	40



# 1 Introduction

## 1.1 Description

The TMS-220 is an I<sup>2</sup>C Bus Host Adapter with a USB interface to the host computer. The TMS-220 uses an ASCII protocol and is backward compatible with our TMS-200 and TMS-210 I<sup>2</sup>C Bus Host Adapters. The TMS-220 connects directly to the USB port of your computer using a standard USB-A Male / USB-B Male cable. The USB port provides power for the TMS-220 therefore no external power supply is required. The TMS-220 serves as an I<sup>2</sup>C bus master or slave that can be controlled by your computer. In order to make the connection to the I<sup>2</sup>C bus, an *interface cable* is provided. The interface cable is terminated with micro grabbers that can be attached directly to pin of an integrated circuit (DIP or SOIC).

## 1.2 Supporting Documents

Reference documents:

- ◆ I<sup>2</sup>C Bus Specification V2.1 (Philips Corporation)  
Visit <http://www.semiconductors.philips.com/buses/i2c> to obtain this document.

## 1.3 Features

Features of the TMS-220 include:

- ◆ Functions as an I<sup>2</sup>C master
- ◆ Functions as an I<sup>2</sup>C slave
- ◆ Supports 7-bit and 10-bit addressing modes
- ◆ User selectable I<sup>2</sup>C bus data rate up to 400 Kbps
- ◆ USB port powered, so external power adapters is not needed.
- ◆ Simple, easy to remember ASCII protocol.
- ◆ Includes USB drivers for the follow operating systems: Windows<sup>®</sup> 98, 98SE, 2000, ME, XP, CE (4.2), and Linux (2.40 and greater).
- ◆ USB driver appears a COM port, so the TMS-220 can work with standard software such as Microsoft<sup>®</sup> Hyper Terminal
- ◆ Easy to program using scripting or macro or high level languages.
- ◆ Data formatting control including Hex dump mode for reading EEPROM memories.

## 1.4 Specifications

The following specifications apply to the TMS-220 Host Adapter:

<b>Interface Module Voltage:</b>	+5V (supplied by the USB port)
<b>Current Draw:</b>	TBD
<b>I<sup>2</sup>C Bus Speed (Master Mode):</b>	40K, 10K, 40K, 100K, 400K
<b>USB Baud Rate:</b>	57.6K
<b>I<sup>2</sup>C Bus Connector:</b>	RJ-45
<b>Mechanical Dimensions:</b>	3 in. x 1.625 in. x 0.750 in.
<b>Operating Temperature:</b>	0°C (32°F) to TBD °C (70°F)

**Table 1-1: Specifications**

## **1.5 Applications**

There are many possible applications for the TMS-220. Here are just a few ideas.

### **◆ Product Development:**

1. Experiment with new I<sup>2</sup>C devices to study their behavior.
2. Debugging new circuit board designs.
3. Program I<sup>2</sup>C serial EEPROM devices during the initial stage of firmware development.
4. Hardware / Software Integration Testing

### **◆ Manufacturing:**

1. Production Test Equipment
2. Serial EEPROM initialization and test. The TMS-220 can be used to read or write any EEPROM that supports the I<sup>2</sup>C protocol.
3. Subassembly testing, especially if the system master is normally contained on a separate circuit board.

### **◆ Electronic Repair and Maintenance:**

1. Equipment calibration.
2. Restore factory default data to EEPROM memories.
3. Security code reprogramming.

## 2 Hardware

### 2.1 Interface Module

The hardware consists of a small plastic enclosure, which contains a microcontroller. The microcontroller connects to your computer's serial port through USB port. Located on the bottom of the TMS-220 is the RJ-45 jack, which is used to connect the TMS-220 to the I<sup>2</sup>C bus. The interface cable plugs into the RJ-45 jack. Image 2.1 shows a TMS-220.



**Figure 2-1:** TMS-220 I<sup>2</sup>C Host Adapter (Interface Module)

## **2.2 TMS-220 Interface Cable**

The Interface Cable supplied with the TMS-220 is terminated on one end with a RJ-45 plug, which is inserted into the TMS-220 interface module. The other end is terminated with pin receptacles, which can be inserted onto the test hooks supplied. The supplied test hooks are suitable for connecting the TMS-220 directly to target circuits.

### **2.3 Custom Interface Solution**

If you would like to create your own custom interface solution, you may purchase a cable without terminations on the target side and connect it however you wish. For example, you may want to use a special connector or you may want to wire it directly to your equipment. Spare (non-terminated) cables may be obtained from Triangle Micro Solutions (option P/N TMS-CBL). The cable supplied is approximately 7 ft. (2.1 m) in length and is terminated only at one end with the RJ-45 connector. Use the information listed in table 2.1 below to determine how to connect the cable to your hardware.



**Figure 2-2:** Cable for Custom Applications (option P/N TMS-CBL)



## 2.4 Interface Cable Data

Information is provided here which may be useful should you decide to create a custom interface solution. Table 2-1 below identifies the function, wire color, and test hook color for both of the cables described in the previous sections. Figure 3.6 (below the table) shows the RJ-45 connector on the TMS-220 with pins 1 and 8 shown as a reference.

Modular Connector Pin Number	Function	Wire Color	Test Hook Colors I <sup>2</sup> C Cable
1	Not Used	Orange	Not Used
2	Not Used	Grey	Not Used
3	Ground	Black	Black
4	SCL (clock)	Green	Green
5	Not Used	Red	Not Used
6	SDA (data)	Yellow	Yellow
7	Not Used	Brown	Not Used
8	Not Used	Blue	Not Used

Table 2-1: Interface Cable Data




Figure 2-3: RJ-45 Connector on TMS-220 (Front View)

### 3 Using the TMS-220

#### 3.1 Installing the TMS-220 Interface Module

To install the TMS-220 Interface Module, connect a USB cable to the interface module and connect the TBD side of the cable to any available USB port on your computer. The first time that you connect the TMS-220, your computer should indicate “new hardware found”. Your computer will ask for the location of a device driver.

#### 3.2 Installing the USB Port Driver

Insert the CD-ROM supplied with the TMS-220 into your CD-ROM drive.

Upon connecting the TMS-220 to your computer’s USB port for the first time, you will see the following dialog window. Select “No, not this time” and select “Next”.



**Figure 3-1:** Found New Hardware Dialog

In the next dialog window, you will be asked how to install the driver software. Choose “Install the software automatically (recommended)” and click “Next” to continue.



**Figure 3-2: Choose Installation Mode**

The next dialog window will indicate that the “USB High Speed Serial Converter” has not passed Windows® Logo testing. Select “Continue Anyway”.



**Figure 3-3: Windows® Logo Test Warning**



**Figure 3-4: Software Installation Progress**



**Figure 3-5: Final Installation Dialog**

The USB High Speed Serial Converter software that you have installed appears as a standard “Com Port” to your software. Therefore there will be a port number assigned to it once it has been installed (for example COM4). This is a virtual com port but to your software it appears as a real com port. This allows you to use common software that was originally designed to work with RS-232 style COM ports.

### 3.2.1 Identifying the Serial Port (COM Port)

When the USB driver is installed, a specific serial port assignment will be made. You will need to know the serial port being used by the TMS-220 so that your application software (i.e. Microsoft® Hyper Terminal) can be configured to communicate with the TMS-220. To determine the serial port selection under Windows® XP, follow these steps:


1. Click the “Start” button in the lower left corner of (Windows® Task Bar).
2. Select “Settings”
3. Select “Control Panel”.
4. From the Control Panel select “System”.
5. In the “System Properties” dialog box, select the “Hardware” tab
6. Select “Device Manager”; within the “Device Manager” dialog box, there should be a tree diagram of all devices installed on the system.
7. Find the branch labeled “Ports (COM and LPT)”. Expand this branch to find the port labeled “USB Serial Port”. This is the port used the TMS-220. The COM port in use will be listed.

### 3.2.2 Changing the Serial Port (COM Port)

The port chosen by the installation software may not be the port that you want to use because it may not be supported by your software. If you want to change the

### 3.3 Connection to I<sup>2</sup>C Bus

Connecting the TMS-220 to the I<sup>2</sup>C bus can be accomplished in a number of ways. The most direct method is shown below in image 3.1, which shows a TMS-200 connected to a I<sup>2</sup>C EEPROM. Consult the chip documentation for I<sup>2</sup>C bus connections on other chips and packages. Note that Image 3.1 shows a TMS-200 connection. A TMS-210 connection must have the RED test clip attached to a suitable voltage source (i.e.: the Vcc pin of the target I<sup>2</sup>C device).



**Figure 3-6:** Typical I<sup>2</sup>C Bus Connection



**WARNING:** Only connect the TMS-220 to target circuits when power is shut off. Take care not to inadvertently allow probes to come in contact with adjacent pins once power is applied.

### 3.4 Software

There is no application software supplied with the TMS-220. To use the TMS-220 you will need either Terminal Emulation Software or custom software that create you self. You may have terminal emulation software installed on your computer (such as Microsoft<sup>®</sup> Hyper Terminal). If you do not have terminal emulation software and you are using the Microsoft<sup>®</sup> OS, you can download the TeraTerm program from the URL listed here.

<http://hp.vector.co.jp/authors/VA002416/teraterm.html>

The TeraTerm program has a built-in macro language that is easy to learn and is ideal for creating simple utilities for use with the TMS-220.

### 3.5 First Time Usage

Once the TMS-220 has been installed and you have it connected to the I<sup>2</sup>C bus, start your terminal emulation software. Pressing the Enter key (CR) should cause the prompt (**TMS-220>**) to be displayed in your terminal window. If you do not see the prompt, consult the Troubleshooting section at the end of this manual. Once you have the prompt, just enter commands as described in section 3.5.

### 3.6 ASCII Command Protocol

The TMS-220 uses a pure ASCII command protocol. All commands begin with the forward slash "/", followed by a letter of the alphabet (case insensitive). Then additional bytes may follow as defined by the specific command. Command arguments may be provided in hexadecimal (0x7F) or decimal (127) notation.

Data output will default to hexadecimal format, but the radix (/X) command permits the user to change the format to decimal. All of the symbols that make up output messages from the TMS-220 are shown in Table 3-1 below.

Symbol	Meaning
S	I <sup>2</sup> C Bus Start Condition
P	I <sup>2</sup> C Bus Stop Condition
A	I <sup>2</sup> C ACK
N	I <sup>2</sup> C NAK
[ ]	Square brackets surround the slave address
00 - FF	Data shown in HEX (no leading 0x)

**Table 3-1:** Output data symbols and their meanings

The default output is structured in a similar manner as an actual I<sup>2</sup>C bus transmission with the START condition represented by the 'S'. Next is the slave address of the I<sup>2</sup>C device that we are sending the message to, surrounded by square brackets. After that, the ACK, is shown (represented by the 'A'). Then the data follows along with ACK's shown as 'A's and NAK's shown as the 'N'. Finally, 'P' indicates the stop condition. This format can be modified using the Display Mode Configuration Command.

Enter commands at the prompt ("**TMS-220>**" or "**TMS-220<**"). Note that the prompt indicates the current mode of the TMS-220 with either the greater than symbol (>) when in slave mode and the less than symbol (<) when in the slave mode.

The TMS-220 supports the *backspace* key to delete characters from the command line. To execute the command, press the <Enter> key. In all of the examples presented in this manual, text entered by the user is shown in **BLUE**. All

commands are terminated with the "Enter" or "Carriage Return" shown like this **<CR>**. Address and data may be entered as hex or decimal. If entered in hex, use the "0x" to denote that the data is hex.

**Example Command:**      **TMS-220> /R 0xA0 0x05 <CR>**

**Example Response:**      **I2C Read:**

**S [A1] A 55 A 55 A 55 A 55 A 55 N P**

**TMS-220>**

NOTE: This space not required



Each command description shows the command syntax. The command syntax field uses angle brackets like **<arg>** to indicate that the argument is required. Optional command arguments are shown enclosed in square brackets like this **[arg]**.



### 3.6.1 Command Summary

Table of commands recognized by the TMS-220:

Command	Arguments	Purpose
/A	[address]	Read or write the slave address for TMS-220 to use when in slave mode.
/B	None	Reset or reboot the TMS-220
/C	None	Display TMS-220 configuration (current state of all module parameters)
/D	None	Discovery command. This command polls to bus to determine what I2C devices are attached
/F	[mode]	Read or write the format control byte. The format control is applied to displayed data in the master mode.
/G	[0 1]	Read or write the general call support control
/H	None	Display help
/K	[0 1 2 3 4]	Read or write the master clock rate
/M	[0 1 2]	Read or write the mode
/R	<address><num>	Master mode read command
/S	None	Display the serial number
/W	<address><data>	Master mode write command
/X	[0 1]	Read of write the radix (supports decimal or hexadecimal)

**Table 3-2:** Summary of Commands

### 3.6.1.1 Command: /A – Address Configuration

Use this command to view the current slave address setting or change the slave address setting of the TMS-220. This command sets slave address values for both 7-bit and 10-bit modes. When there are no arguments supplied, the TMS-220 will return the current setting. When one argument is supplied, the TMS-220 will write a 7-bit address. When two arguments are supplied, the TMS-220 will write a 10-bit address.

**Command Syntax:**     /A [address]

**Arguments:**           *address* – (optional): When supplied, the *address* argument is configured as the new slave address. The *address* argument may be supplied as an 8-bit argument in the range of 0 – 255 decimal (0x00 – 0xFF Hex), or as a 16-bit value (for 10-bit addressing modes).

**Example 1:**           Read the current slave address setting.

```
TMS-220> /A <CR>
Slave address (7-bit): 50
Slave address (10-bit): FF50

TMS-220>
```

**Example 2:**           Write a 7-bit address.

```
TMS-220> /A A0 <CR>
Slave address (7-bit): 50
Slave address (10-bit): FF50

Setting 7-bit slave address to: A0

TMS-220>
```

**Example 3:**           Write 10-bit address.

```
TMS-220> /A F0 10 <CR>
Slave address (7-bit): 00
Slave address (10-bit): FF00

Setting 10-bit slave address to: F010

TMS-220>
```

### 3.6.1.2 Command: /B – Reboot the TMS-220

Use this command to reboot the TMS-220.

**Command Syntax:** /b

**Arguments:** None

**Example:** Reboot the TMS-220

```
TMS-220> /B <CR>  
Rebooting...
```

```
TMS-220 I2C Host Adapter  
V0.0.0 Built Nov 06 2006 at 22:42:25.  
Copyright(c)2005 Triangle Micro Solutions, All  
rights reserved.  
www.TriangleMicro.com
```

```
TMS-220>
```

### 3.6.1.3 Command: /C – Show the Current Configuration

This command is used to show the current configuration of the TMS-220. Once issued, the TMS-220 displays current settings which are stored in non-volatile memory.

**Command Syntax:** /C

**Arguments:** None

**Example:** Display the current TMS-220 configuration.

```
TMS-220> /C <CR>
```

```
TMS-220 Configuration
```

```
=====
```

```
Serial number ..... 12345
Operational Mode ..... I2C Master
Show NAK ..... ON
Show ACK ..... ON
Show START ..... ON
Show STOP ..... ON
Memory dump mode ..... OFF
Master clock rate ..... 100K
Radix ..... HEX
Slave Address (7-bit)... 50
Slave Address (10-bit).. FF50
General call support ... DISABLED
```

```
TMS-220>
```

#### 3.6.1.4 Command: /D – Discover Network Nodes

Use the discover command to identify all slave devices attached to an I2C bus. The command will poll 0x00 – 0xFC will be polled to determine which devices are active.

**Command Syntax:** /D

**Arguments:** None

**Example:** Poll addresses and show ACK / NAK result. Note, to save space only the first two and last two are shown in this example.

```
TMS-220> /D <CR>
Polling the network...
Polled 00 got NAK.
Polled 02 got NAK.
.....
Polled FA got NAK.
Polled FC got NAK.
Done.

TMS-220>
```

### 3.6.1.5 Command: /F – Format Options

The data output format may be altered using this command. When setting the display mode, one argument is supplied. The display configuration data is bit-wise encoded as described in table 3.3 below.

**Command Syntax:**        /F [mode]

**Arguments:**            *mode* - (optional): When not supplied, the current value is displayed. To write a new display mode, send the command with the **mode** argument. Encode the bits as shown in the table. The default value at power-up is 0x0F.

**Example:**                Configure the TMS-220 to output data in "memory dump" format. In this format, data is displayed in columns with the left most column containing the address.

```
TMS-220> /F 0x10 <CR>
```

```
Memory dump mode enabled.  
Format options = 0x10
```

```
TMS-220>
```

BIT	Control Byte - FORMAT_OPTIONS
0	Show NAK responses (Default = 1 - Enabled)
1	Show ACK responses (Default = 1 - Enabled)
2	Show START condition (Default = 1 - Enabled)
3	Show STOP condition (Default = 1 - Enabled)
4	Enable memory dump format for output. (Bits 0 - 3 must be 0 in this mode) (Default = 0 - Disabled)
5	Not Used - Leave as 0
6	Not Used - Leave as 0
7	Not Used - Leave as 0

**Table 3.3:** Display Mode Output

### 3.6.1.6 Command: /G – General Call Support

This command is used to enable the general call support feature to be enabled or disabled.

**Command Syntax:**        /G [mode]

**Argument:**                *mode* – (optional): When supplied, the mode condition is updated and saved. When mode is supplied as 0, the general call option is disabled. When mode is supplied as 1, the general call support is disabled.

**Example 1:**                This example shows the current general call support configuration

```
TMS-220> /G <CR>
General call support: DISABLED

TMS-220>
```

**Example 2:**                This example enables the General Call support feature.

```
TMS-220> /G 1 <CR>
General call support: DISABLED
Enabling General Call Support
General call mode successfully updated

TMS-220>
```

### 3.6.1.7 Command: /H - Help Command

The help command provides a list of all commands available, the syntax for each command, and the arguments for each command. Arguments shown in [ ] brackets are optional. Arguments shown in < > brackets are required. In addition, the current firmware version is also shown.

**Command Syntax:** /H or /h or /?

**Arguments:** None

**Example:** Display help screen.

TMS-220> /H <CR>

TMS-220 I2C Host Adapter  
V0.0.0 Built Nov 06 2006 at 22:42:25.  
Copyright(c)2005 Triangle Micro Solutions, All rights reserved.  
[www.TriangleMicro.com](http://www.TriangleMicro.com)

Help command

Usage:

/A [address]	- Write slave address (0x50 is default) (slave mode only)
/B	- Reset (reboot) the TMS-220
/C	- Show current TMS-220 configuration
/D	- Poll all I2C addresses to discover what devices are available
/F [mode]	- Format output data (0x0F is default) Argument [mode] is bit mapped as follows: Bit 0 - Show NAK Bit 1 - Show ACK Bit 2 - Show START Bit 3 - Show STOP Bit 4 - Memory dump mode Bits 5 - 7 are not used
/G [0 1]	- General call support (slave mode only) 0 - Disabled (default) 1 - Enabled
/H	- Show this HELP screen (also /?)
/K [0 1 2 3 4]	- Set the master mode clock 0 - 40K bits 1 - 80K bits 2 - 100K bits 3 - 200K bits 4 - 400K bits
/M [0 1 2]	- Show or set the mode 0 - I2C Master Mode (Default) 1 - I2C 7-bit slave 2 - I2C 10-bit slave
/R <addr> <num>	- Read from slave I2C device addr - I2C Device Address num - Number of bytes to read from addr
/S	- Display the TMS-220 serial number
/W <addr> <d1..dn>	- Write data to slave I2C device
/X [0 1]	- Set radix 0=Hex (default) 1=Decimal

Square brackets [ ] indicate optional arguments.

Angle brackets < > indicate required arguments.

TMS-220>

Copyright © 2007 - Triangle Micro Solutions, Inc. All rights reserved.



### 3.6.1.8 Command /K: Set or Read the Master Clock Rate

Use this command to set the master mode clock rate to one of the following values: 40Kbps, 80Kbps, 100Kbps, 200Kbps or 400Kbps. The command may also be used to read the current clock rate. The clock rate being set or read is relevant to the master mode of operation only.

**Command Syntax:**     /K [rate]

**Arguments:**         *rate* – (optional): When supplied, the bit rate for the I<sup>2</sup>C bus clock is updated to the value represented by rate (0-4).

**Example 1:**           Read the current I<sup>2</sup>C bus clock rate.

```
TMS-220> /K <CR>
Current I2C master clock rate is: 100K
```

**Example 2:**           Set master clock rate to 400K.

```
TMS-220> /K 4 <CR>
Current I2C master clock rate is: 100K
Requested I2C master clock rate is: 400K
I2C master clock successfully updated.
```

### 3.6.1.9 Command /M: Set or Read the Mode

The command is used to set the mode of the TMS-220. The TMS-200 can be operated in one of three modes: bus master, slave (7-bit addressing) or slave (10-bit addressing.) The mode can be determined by observing the prompt.

**Command Syntax:**        /M [mode]

**Arguments:**            *mode* – (optional): When supplied, this specifies the desired operating mode as follows:

- 0 = Master Mode (default)
- 1 = Slave Mode (7-bit addressing)
- 2 = Slave Mode (10-bit addressing)

**Example 1:**              Show the current mode.

```
TMS-220> /M <CR>
Current mode is: I2C Master

TMS-220>
```

**Example 2:**              Set the mode to slave mode with 7-bit addressing.

```
TMS-220> /M 1 <CR>
Current mode is: I2C Master
New mode selection: I2C 7-Bit Slave
Mode successfully updated.

TMS-220<
```

**Example 3:**              Set the mode to slave mode with 10-bit addressing.

```
TMS-220> /M 2 <CR>
Current mode is: I2C Master
New mode selection: I2C 10-Bit Slave
Mode successfully updated.

TMS-220<<
```

**Example 4:**              Set the mode to master mode.

```
TMS-220<< /M 0
Current mode is: I2C 10-Bit Slave
New mode selection: I2C Master
Mode successfully updated.

TMS-220>
```

### 3.6.1.10 Command /X: Radix Control

Use this command to view and modify the current radix for output data. The default value is 1, which indicates the radix is base 16 (HEX). Setting the value to 0 makes the radix base 10 (decimal). This affects the data fields in the output from both the read or writes commands.

**Command Syntax:**     /X [radix]

**Arguments:**           *radix* - (optional): When not supplied, the command responds with the current radix setting. When supplied, it should only be 0 or 1.

1 = Format data in hex (default)  
0 = Format data in decimal.

**Example 1:**           Set the radix to base 10, decimal.

```
TMS-220> /X 0 <CR>
```

```
Radix is DEC
```

**Example 2:**           Set the radix to base 16, hexadecimal.

```
TMS-220> /X 1 <CR>
```

```
Radix is: HEX
```

```
Setting radix to: DEC
```

```
Configuration successfully updated
```

```
TMS-220>
```

### 3.6.1.11 Command /R: Read I<sup>2</sup>C Slave Device

This command initiates a write operation to a device on the I<sup>2</sup>C bus. There are two required arguments. The first argument is the slave device address. The second is the number of bytes that you want to read. The format of the output from this command may be altered by using the /F (format control) command.

**Command Syntax:**            /R <address> <num\_bytes>

**Arguments:**                *address* (required) - The address of the slave device that the read command is intended for.

*num\_bytes* (required) - The number of bytes to be read from the slave device.

**Example 1:**                Read 5 bytes from the current address of a 24C04 EEPROM.

```
TMS-220> /R 0xA0 0x05 <CR>
```

```
I2C Read:
```

```
S [A1] A FF A FF A FF A FF A FF N P
```

```
TMS-220>
```

### 3.6.1.12 Command: /S Serial Number

Display the serial number of the TMS-220.

**Command Syntax:** /S

**Arguments:** None

**Example:** Read the TMS-220 serial number.

```
TMS-220> /S <CR>
```

```
TMS-220 Serial Number: 1234
```

```
TMS-220>
```

### 3.6.1.13 Command /W: Write to I<sup>2</sup>C Slave Device

This command performs a write operation to an I<sup>2</sup>C device on the bus. This command can be supplied with a variable number of data arguments. An optional repeat start condition is allowed with this command. The use of the repeat stop is shown in the second example.

**Command Syntax:**        /W <address> <data> ... <data> [S]

**Arguments:**            *address* (required): The address of the device that you are writing to.

*data* (required): The data to be written. At least one data byte is required. The maximum number of data bytes is limited by the size of the command line buffer and depends on how data is entered. For example, using '5F' instead of '0x5F' will permit more data to be entered into the buffer.

*S* [optional]: This argument enables the repeat start condition.

**Example 1:**            Write the address byte of a 24C04 EEPROM to 0x00.

```
TMS-220> /W 0xA0 0x00 <CR>
```

```
I2C Write:  
S [A0] A 00 A P
```

```
TMS-220>
```

**Example 2:**            Perform a random read from a 24C256 serial EEPROM. This example shows how to use the repeat start feature. This operation must be performed in two steps. First, setup the address registers using the /W command terminated with a repeat start condition. Next, read data from the EEPROM using the /R command.

```
TMS-220> /W 0xA0 0x00 0x00 S <CR>
```

```
I2C Write:  
S [A0] A 00 A 00 A S
```

```
TMS-220> /R 0xA0 0x05 <CR>
```

```
I2C Read:  
S [A1] A 00 A 00 A 00 A 00 A 00 N P
```

```
TMS-220>
```

### 3.7 I<sup>2</sup>C Master Operating Mode

When the TMS-220 is in I<sup>2</sup>C Master Mode, the following prompt is displayed:

```
TMS-220>
```

Enter commands at the prompt. The <BACKSPACE> key can be used to correct mistakes. Press the <ENTER> (or <CR>) key to execute a command.

In master mode, I<sup>2</sup>C slave devices can be read using the read command as shown below:

```
/R <address> <num_bytes>
```

See the documentation in the previous section for examples. In order to use the read command, the slave address must be known. The data sheet for the device that you wish to read data from should be consulted to determine the address. Some devices may respond to multiple addresses, depending on pin programming or register programming.

### 3.8 I<sup>2</sup>C Slave Operating Mode

When the TMS-220 is in I<sup>2</sup>C Slave Mode, the following prompt is displayed:

```
TMS-220<
```

When an I<sup>2</sup>C master addresses the TMS-220 operating in slave mode for the purpose of writing data to it, the TMS-220 will display an exclamation mark to indicate that it is receiving data from a bus master. The TMS-220 will then display its address followed by all of the data received from the slave.

The following example illustrated the process:

Master Sends:		TMS-220 Slave (address = 0x50) Output:
Address:	0x50	TMS-220< ! 50 AA 55 AA 55
Data Byte 1:	0xAA	
Data Byte 2:	0x55	
Data Byte 3:	0xAA	
Data Byte 4:	0x55	

**Figure 3-7:** TMS-220 Slave Response to Write Command

When an I<sup>2</sup>C master addresses the TMS-220 operating in slave mode for the purpose of reading data from it, the TMS-220 will display a question mark prompt, and wait for data to be supplied.

The following example illustrated the process:

Read 5 bytes from the slave device who's address is 50 hex.		TMS-220 Slave (at address = 0x50)	
Master Sends:		Output:	
Address:	0x50	TMS-220<	
Data Byte 1:	0x05	? AA ← Enter data at '?' prompt	
		? 55 ← Enter data at '?' prompt	
		? AA ← Enter data at '?' prompt	
		? 55 ← Enter data at '?' prompt	
		? AA ← Enter data at '?' prompt	

**Figure 3-8:** TMS-220 Slave Response to Read Command



## 4 Troubleshooting

This section is provided to assist users of the TMS-220 to troubleshoot and fix problems that might arise. Should you encounter a problem that can not be solved using the information that is contained here, contact [service@trianglemicro.com](mailto:service@trianglemicro.com) for assistance.

### 4.1 No Prompt Seen when Enter Key Pressed

If you do not see the TMS-220 prompt, follow the check list below.

1. Verify that you have the correct communications port selected for the software that you are using, and that the TMS-220 is connected to the port that you have selected.
2. If you are using terminal emulation software (such as TeraTerm), verify that the proper communications port has been selected in the applications configuration dialog.
3. Verify that your software is configured for the correct serial port, and that the communications parameters are set as shown in table 4.1 below.

Parameter	TMS-220
Baud Rate	57,600
Data Bits	8
Parity	None
Stop Bits	1
Flow Control	None

**Table 4.1:** Serial Port Parameters

4. Verify that the target circuit is powered.
5. After checking all of these things, if you still are having difficulty, try disconnecting the TMS-220 from the host, wait 10 seconds and then reconnect it to the host. The boot up message should appear on the terminal window.

## 4.2 Error Messages

The following table summarizes the various error messages that may be displayed by the TMS-220 along with the probable cause and the commands that are capable of generating them.

No.	Error Message	Cause	Commands
1	ERROR: Failed to save mode	Configuration data not saved to internal memory.	/F
2	ERROR: No change in value	Supplied argument is the same as current configuration. No change made.	/F, /G, /K, /M, /X
3	ERROR: Syntax error	The command was not formatted properly or the command is not a valid or supported command.	/F, /G, /K /X, /A
4	ERROR: Too many arguments	There were more arguments than expected supplied with the command. Consult the section of this document for the command to see the required and optional arguments.	/F, /G, /K, /X, /R, /A
5	ERROR: Failed to save configuration change	Configuration data not saved to internal memory.	/G, /K, /M, /X
6	ERROR: Invalid rate (use: 0=40K, 1=80K, 2=100K, 3=200K, 4=400K)	Rate requested is not available. Choose another rate from the selection.	/K
7	ERROR: Invalid mode requested	Requested mode is not available. Choose another mode.	/M
8	ERROR: Invalid radix (0=HEX, 1=DEC)	Radix code is not available. Choose a radix code from the list supplied (0 or 1).	/X
9	Syntax error - Invalid slave address.	The slave address is not valid. Choose a valid address.	/R, /A
10	Command not available in slave mode.	The read command is not supported when the TMS-220 is configured as a slave device.	/R, /W
11	ERROR: Upper byte of 10-bit slave address must be B'1111.0XX[R/W]	The slave 10-bit slave address was not correct. Try another address that follows the supplied pattern.	/A

## End of Document